


Underground CP

Anode Centralizer for Groundbed



Centralizer is used in a groundbed hole to maintain a more uniform CP current distribution from the anode by ensuring consistent backfill cover. In addition, maintaining proper spacing between the anode and non-conductive gas vent pipe is also an important function for the anode centralizer.